



MIROTONE

Printing

Marks or fingerprints in the coating.

Cause	Prevention
Coating film marking after being packed and transported too soon.	<p>Allow coating to dry for the time indicated on the product data sheet, before packing and transporting.</p> <p>Choose a more suitable thinner which will enable the coating to dry quicker which will enable the product to be packed sooner.</p> <p>Force dry the coating system before packing and transporting.</p> <p>If two component coating system has been used ensure that the coating has been mixed correctly.</p>